



HALO MINI SERIES & HALO GUARDIAN LIMITED WARRANTY

WHAT YOUR WARRANTY COVERS

THE HALO MINI SERIES 2 STAGE, MINI SERIES 3 STAGE & HALO GUARDIAN WHOLE HOUSE WATER SYSTEMS ARE WARRANTED TO THE ORIGINAL OWNER AT THE ORIGINAL RESIDENTIAL INSTALLATION LOCATION TO BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP FROM THE DATE OF MANUFACTURE AS SPECIFIED.

- 1.) HALO WILL PROVIDE ONE REPLACEMENT TANK FOR ANY TANK THAT FAILS DUE TO A MANUFACTURING DEFECT.
- 2.) HALO WARRANTS THAT COMPONENTS FOR THE EQUIPMENT WILL BE AVAILABLE FOR THE LIFETIME OF THE SYSTEM.
- 3.) HALO WILL PROVIDE COMPARABLE COMPONENTS OF OUR SELECTION TO REPLACE ANY OBSOLETE ITEMS.
- 4.) THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS THAT MAY VARY FROM STATE TO STATE.

CONDITIONS OF WARRANTY

- 1.) THE SYSTEM MUST BE INSTALLED AND MAINTAINED ACCORDING TO LOCAL CODES AND SECONDARILY IN ACCORDANCE WITH MANUFACTURER RECOMMENDATIONS. CONTACT HALO IF THERE ARE ANY CONFLICTS BETWEEN LOCAL CODES AND OUR PRINTED INSTRUCTIONS.
- 2.) THE SYSTEM MUST BE MAINTAINED WITH HALO APPROVED REPLACEMENT COMPONENTS.
- 3.) FAILURES RESULTING FROM FIRE, FREEZING, NEGLIGENCE, ACCIDENT, ALTERATION, ABUSE, IMPROPER INSTALLATION OR ACTS OF NATURE ARE NOT COVERED.
- 4.) WATER PRESSURE MUST BE REGULATED BETWEEN 40 TO 80 POUNDS PER SQUARE INCH WORKING OR STATIC PRESSURE. PRESSURE EXCEEDING 80 POUNDS PER SQUARE INCH WORKING OR STATIC PRESSURE VOIDS ALL WARRANTY.
- 5.) AIR TEMPERATURE EXCEEDING 120 DEGREES FAHRENHEIT VOIDS WARRANTY ON FILTER HOUSINGS.
- 6.) INFLUENT CHLORINE MUST NOT EXCEED 1 MG/L.
- 7.) HALO DOES NOT WARRANT TO PERFORM, PAY FOR, OR FINANCE ANY REPAIRS AND/OR INSTALLATIONS. THE CUSTOMER MUST CONTACT THE HALO REPRESENTATIVE.
- 8.) IF A RECIRCULATION PUMP IS IN USE AT THE LOCATION OF THE HALO INSTALL A SECONDARY CONDITIONER MUST BE INSTALLED IN ORDER TO ENSURE OPTIMUM RESULTS.

OBTAINING WARRANTY SERVICE


ALL RETURNS MUST BE ACCOMPANIED BY A "RETURN AUTHORIZATION" (RMA) NUMBER. ALL DEFECTIVE WARRANTED PART(S) ALONG WITH A COPY OF THIS WARRANTY, ORIGINAL PURCHASE RECEIPT AND THE RMA NUMBER. WE WILL, AT OUR OPTION, REPAIR OR PROVIDE REPLACEMENT WARRANTED PARTS AT NO COST, EXCEPT FREIGHT AND ON SITE LABOR CHARGES. YOU CAN CONTACT US AT (800) 591-0538 OR EMAIL US AT WARRANTY@HALOWATER.COM.

LIMITATIONS AND EXCLUSIONS

THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ANY OTHER WARRANTY EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OF FITNESS FOR PARTICULAR PURPOSE. HALO SHALL NOT BE LIABLE FOR ANY LOSS OR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE MISUSE OR INABILITY TO USE THIS EQUIPMENT BY THE BUYER OR ANY USER.

HALO Guardian

Install Diagram for most Water Heaters



Please Note: HALO Guardian is rated for cold water treatment only.

Install on the cold water inlet of water heater.

If recirculating loop is present, you must install a check valve to prevent thermal expansion in to GUARDIAN

DO NOT RUN HOT WATER through HALO GUARDIAN unit.