



QUICK REFERENCE PROGRAMMING GUIDE H-IS

If the head on your HALO System does not look like the image to the right, you need to remove the weatherproof cover over it.

1. Set the time of day

Hold the **set** button for 5 seconds, then use the **▲** or **▼** buttons to select the current hour.

Note: The hour is AM unless PM is indicated by the **►** pointing at the PM on the right side of the display screen.

Press the **set** button again to adjust the minutes.

2. Select system regeneration settings

Hold the **set** button and the **▲** simultaneously for 3 seconds, until the digital display flashes. Adjust the time for regeneration to a time when minimal water is being used. Press the **set** button again to accept the setting and advance to the next step in the programming process.

3. Days between regeneration cycle

Set regeneration to occur every **3 days**

Press the **set** button to accept the setting and advance to the next step in the programming process. You will return to the home screen.

4. Verify system regeneration cycle

Hold the **set** button and the **▲** button simultaneously for 3 seconds. Let go and then hold the **set** button and the **▲** button simultaneously again for 3 seconds **P7** should be displayed. If this screen does not display **P7**, press the **▲** or **▼** buttons until **P7** is selected. Press **set** to accept this setting. Press **set** again. You should now see the number **99** with a blinking arrow next to **days to regen** on the bottom right of the display screen. If you see the number **7** instead of **99** press the **▲** or **▼** button until the number **99** appears, then press **set**, dP will flash **12 hr** will be displayed, press **set** again to return to the main screen.



5. Main screen will now display time

Press the **▲** or **▼** button to toggle between time of day and days until next regeneration. Confirm the system regeneration is scheduled for the number of days you selected in step 3.

Programming is now completed!

E1 or E2 error codes

If the screen displays an E1 or E2 error code, hold **set** and **▼** buttons until you hear the gear recenter, then release buttons.

IMPORTANT

It is now essential the you force 2 regenerations.

Next run water from each fixture in the home for **2 minutes** to completely flush the system. If water remains cloudy and repeat the process and force 2 regenerations, then run water again for **2 minutes** from every fixture.

If forced regenerations are not performed customer will likely complain about water quality.